



- Accessories
- To connect the Zero Smog TL to one or two WT or WX soldering stations (please note: WX connecting cable T0058764710 needed)
- Enables cost-efficient and synchronized usage of devices - the fume extraction unit works only while the operator is soldering
- Quick and easy set-up

### WT HUB

Product no.: T0058768767

Dimensions L x W x H (mm)	---
Dimensions L x W x H (inches)	---
Weight (approx.) in kg	---
Voltage	---
Power	---
Channels	---
Temperature range (depends on tool) °C	---
Temperature range (depends on tool) °F	---
Temperature accuracy °C	---
Temperature accuracy °F	---
Temperature accuracy for hot air °C	---
Temperature accuracy for hot air °F	---
Temperature stability °C	---
Temperature stability °F	---
Equipotential bonding socket	---
Display	---
Additional vacuum pump	---
Max. hot air flow rate l/min (depends on tool)	---
Capacity l/min	---
Max. vacuum	---
Interface	---